

## VHA300 Dimming Operating Instructions

### 1. Connect VHA300

Before setting VHA300, please use laptop, smart phones, IPAD and other terminal devices to connect VHA300

- Wireless SSID (wireless name) factory values defaults: VHA300\_MAC last six data.
- Wireless factory password defaults: 12345678.

Tips:

- (1) When use computer wireless connection to connect VHA300, please turn off the computer's local connection.
- (2) When use computer wired connection to connect VHA300, please turn off the computer's wireless network.
- (4) Set your computer to automatically obtain IP address.

### 2. Configure VHA300

- 1) Open a browser, enter the domain name: <http://vonets.cfg> to enter the configuration interface.
- 2) Super-user access to web pages that can be configured GPIO.  
Super-user SSID: root  
Password: vonets\*\*\*pl
- 3) Enter the configuration interface to configure GPIO, the user can view the state of the lamp according to the configurable GPIO contents.
- 4) VHA300 currently with two inputs, two outputs.
  - (1) After entering the ON / OFF switch input, along with pressing movements, lights on or off.
  - (2) After binding pwn:
    - a) Select the loop dimming, lamp brightness changes.
    - b) Choose rise dimming, after the brightest lights, and then enter, lights unchanged.
    - c) Select the drop dimming lights dimmed, and then pressed, lamp status unchanged.
    - d) select switch dimming, the lights status flip with button.

Tips:

1.VHA300 with 3 buttons:

(1) the reset button: long press for reset, single press for power on or shut down.

(2) 02 key: the corresponding GPIO\_2 of configuration interface .

(3) 16 key: the corresponding GPIO\_16 of configuration interface.

2. GPIO input setting, GPIO\_2 or GPIO\_16 either simultaneously bind GPO\_18 and GPO\_19, or not binding, which can not only bind one.

VONETS.COM