

### VM300—Connection method of serial port

About connection method of serial port, please refer to the following picture:

